



PHONE SET-UP

1. Plug the **White Cambium** phone box into power source using black power cable in box. Make sure lights turn on.
2. Plug the blue cable in box into the blue port on white cambium box. Then plug other end into your existing router into port 1 or lowest port denomination available.
3. Plug your phone line into the white cambium box into **Line 1 only**. **Line 2 will not work**.
4. Allow for a few minutes for service to turn on. Then you should be able to pick up phone and hear a dial tone.

**For Voicemail Dial *97
and then enter your pin.**

One time activation fee of **\$19.95**
will be applied upon activation.
\$19.95/MONTH for service.