















ROKU REMOTE



BUTTON LIST

-  Power Button
-  Roku Home Button
-  Back Button
-  OK / Enter Button
-  Vertical / Horizontal Navigation Buttons
-  Options Button
-  Voice Command Button
-  Reverse Seconds Button
-  Pause / Play Button
-  Reverse / Fast-Forward Button
Forward / Reverse Page in Guide / Channel List
-  Volume Up Button
-  Volume Down Button
-  Mute Button